



motofusion

SPORT BIKE ACCESSORIES

INSTALLATION INSTRUCTIONS

PRODUCT: **Frame Sliders (Crash Protectors) (KTM Duke)**

DIFFICULTY: 3/10

TIME: 15-30 minutes approx.

FITS:

KTM 200 Duke: 2012-14, 2015-16, 2017+

KTM 250 Duke: 2017+

KTM 390 Duke: 2013-16, 2017+

Bajaj Pulsar 200NS

Bajaj Pulsar 200AS



TOOLS REQUIRED:

1. Allen Key: Size 6 (Available in Bike's Toolkit)
2. Allen Key: Size 5 (Available in Bike's Toolkit)
3. Spanner: Size 14
4. Thread Locker: Medium Strength
(Optional, but Recommended)
5. WD 40: (Optional, but Recommended)

INCLUDED IN THE BOX:

- A. Frame Slider (Pre-assembled) (2 Nos)
- B. M8 Socket Head Bolt (4 No)



INSTRUCTIONS

1. Remove the stock leg guard by removing bolts/nut (P,Q)
2. Reinstall the fasteners after removing stock leg guard.

TIP: Do the full process one side at a time.



3. Remove bolts M and N



INSTRUCTIONS

4. Clean the holes using WD40, if necessary.
5. Insert 2 bolts through each of the holes on the base aluminium.
6. Put a small amount of Thread Locker on the bolt's threads at the bottom end.

TIP: The Thread Locker dries quickly. Hence, install the assembly within 2 minutes of applying the thread locker. If it has already dried, first clean the threads properly and reapply the thread locker, before installing it on the bike.

7. Insert the full assembly through holes (M, N) and tighten it with Allen Keys. (Max Torque: 18Nm)

8. Repeat the steps for other side.



FINAL LOOK



VISION
ACCESSORIES

